



Eco Roll-up Banner Display



IMPORTANT - Do NOT remove the Locking Pin until shown.

1 Fitting top of Banner to Top Rail


- i) Peel 100mm of protective strip from the Top Rail. With the image face side **downwards** attach one corner of the Banner to the Rail.
- ii) Hold the Banner in line while gently removing the remainder of the protective strip.



2 Fitting bottom of Banner to the Box 'Apron'


Remove the protective strip from the tape on the Apron. Follow the printed black line & apply the Banner with the image face side **upwards**.

Important Use a strip of self adhesive tape, Sellotape or similar, to tape down the bottom edge of the Banner to the 'Apron'.





3 Loading the Banner



- i) Hold the Apron against the Box with your left hand. Slowly remove the Locking Pin. ii) Hold the Banner at the sides & guide it while it retracts into the Box.




4 i) Rotate Feet.



iii) Place the Pole into the Hook in the Top Rail & into the Hole in the Box.



Rear view of Eco Roll Up Banner.



Although this is generally a one banner display/storage system, banners can be changed by fully extending the display & fitting the locking pin, removing the Sellotape & cutting the 'apron' & banner top to remove the adhesive join, then applying a new strip of double-sided tape to both.